


How To Measure Assemblies

The overall length of the hose assembly is measured to the sealing surface of straight fittings or to the center line of elbow fittings. As the following:

软管总成长度表示方法 How to measure Assembly

软管总成长度L 以从接头芯端面或弯接头芯中心为基准进行测量。




How To Measure Displacement Angle

软管总成装配角表示方法

How to Measure Displacement Angle

置胶管总成在同一直线上,其中一个接头为垂直方向;按顺时针方向测量另一个接头与垂直方向接头之间的夹角。此夹角即为装配角。



装配角允许误差 $\pm 3^\circ$